



Fitting Instructions

AD62U

For;
Audi A3 Sportback 2016-
With shelf style rear bumper
(often pre-cut)

MATERIALS

A	1	Cross Bar
B	2	Sidearm
C	4	M12 x 45 x 1.75 bolts, flat washers (40 O.D), Nyloc nuts (x2), square nuts ("T" type) and retainers (x2).
D	4	M12 x 35 x 1.75 bolts, flat washers and Nyloc nuts.
ZE	1	Electric plate.
ZN	1	Neck kit

FITTING

1. Remove light clusters – to remove light clusters peel back trim within the boot behind the lights, un-screw black square peg and pop lights out to give access to the electrical connection that can be un-clipped for complete removal if necessary.
2. To remove bumper, remove 2 screws on lower edge, remove screws within wheel arches, one fixing from beneath each light cluster and 4 bolts from within the rear of the boot panel (requiring a 10mm box spanner). Carefully prise plastic clips and slide bumper rearwards taking care to unclip any electrical connections before complete removal.
3. Remove crash beam and hand to end user for re-fitment when bar is removed. **Refit bolts to rear panel to prevent ingress of water.**
4. Insert Caged Nuts into the Side Arms D. (Use Cage Nut installation guide to assist with fitment). Loosely attach Side Arms to existing side mountings inside the chassis (may have to remove tape covering holes) using fixtures E in correct locations.
5. Attach Cross Bar (A) using fixtures F to the Side Arms. **Fully Tighten Bolts to recommended settings.**
6. Refit Bumper
7. Please refer to neck fitting instruction for fitting the neck – enlarging the existing aperture on certain models will improve access to neck bolts.
8. Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**

Recommended torque settings: M12 - 95 Nm, M16 - 214 Nm

