



Fitting Instructions

TOWBAR DA771U
For Dacia Sandero/Stepway
2021-

MATERIALS

A	1	Main Crossbar.
C	2	Sidearms.
D	4	M12x40x1.75 Bolts, Lock washers and flat washers 30o/d Note: (Use M12x40x1.75 Bolts at "D")
E	4	M12x35x1.75 Bolts and Nyloc Nuts
F	2	M6x20x1.0 Bolts, 4x Flat washers and nuts.
ZE	1	Electrical Plate.
ZN	1	Neck Option.

Note: This towbar must be used with either a Witter Towball (part number Z11) or Class A50-1 or A50-X towball, which dimensionally conforms to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

FITTING

- To Remove bumper:** Remove covers inside boot either side to reveal hand turns to release light clusters, undo two screws under the light clusters when removed, undo fixings inside wheel arches each side and along bottom of bumper.
- Release bumper from wheel arches to rear panel, undo wiring for parking sensors etc.
- Remove crash beam which includes bumper supports, and hand to customer.
- Loosely attach sidearms (C) using fixings (D), attach Main crossbar (A) with fixings (E).
- Cut bumper to suit chosen neck (see below), fit Electrical plate.
- Tighten all fixings to correct torque settings, replace bumper (reverse of removal) before using tabs attached to main crossbar (A) to bumper skirt

NOTE: ALL DIMENSIONS ARE APPROXIMATE.

Recommended torque settings: Grade 8.8 bolts: M8 - 24Nm, M10 - 52 Nm, M12 - 80 Nm, M14 - 130 Nm, M16 - 200 Nm
Grade 10.9: M12 - 120Nm, M10 - 70Nm M8- 35Nm

