



Fitting Instructions

TOWBAR **HN61AU**
For Honda Civic **For**
2006 - **HN61AQ**
HN61AQF

MATERIALS

A	1	Cross Bar
C	1	Left Sidearm
D	1	Right Sidearm
E	2	Bushes (41mm O.D, 24mm Long)
F	4	M12 x 30 x 1.75 Bolts, Lock Washers and Flat Washers (40mm O.D)
G	4	M12 x 35 x 1.75 Bolts, Nuts, Lock Washers and Flat Washers (25mm O.D)
H	4	M8 x 25 x 1.25 Bolts, Lock Washers and Flat Washers (25mm O.D)
J	1	M16 x 100 x 2.0 Bolt, Nut & Lock Washer.
ZE	1	Electrical Plate (ZEP2)

For use with either

HN61AQ Detachable neck option – ZQ2008.

HN61AQF Flange Detachable neck option – ZQF2008.

FITTING

1. Remove mud flaps (only on certain models) 1 off screw on outer edge of wheel arch, 1 off plastic push clip on inner edge of wheel arch and 1 off plastic screw on under section.
2. Remove Bumper, 6 off plastic push clips along lower edge, 2 off hex head screws under plastic covers in boot opening. Loosen outer wheel arch trims and remove 1 off plastic push clip and 1 off screw securing bumper. Pull bumper out sideways at wheel arch and then slide bumper rearwards.
3. Remove crash beam, 6 off hex head screws and slide beam upwards to release. (**Note:** Hand crash beam to final user for refitting if towing bracket is removed)
4. Loosely attach Sidearms (C&D) using fixings (F&H).
5. Attach Crossbar (A) using fixings (G&J) with bushes (E) in position to clamp around towing eye using fixing (J). **Fully Tighten all Fixings.**
6. Cut bumper as shown and refit.
7. Attach Detachable Neck (ZQ) as per separate fitting instruction.

Note:

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

