



Fitting Instructions

TOWBAR HY39AU-FIT
For Hyundai Getz
September 2005 –
(Fog light in centre of bumper)

For use with 2031 series necks.

MATERIALS

A	1	Cross Bar
D	2	M12 x 45 x 1.25mm Fine Pitch Bolts, Lock Washers and Flat Washers (30mm O.D.)
E	1	Spacer Plate
F	2	M12 x 35 x 1.25mm Fine Pitch Bolts, Lock Washers and Flat Washers (30mm O.D.)
EP	1	Electrical Plate (ZEP2)
BC	4	M12 Bolt Caps

FITTING

1. Temporarily remove 2 rearmost exhaust hangers and lower exhaust.
2. Loosely attach Cross Bar (A) to existing captive nuts in chassis using Bolts (D) and Spacer Plate (E) on right hand side, and Bolts (F) on left hand side.
3. Attach Detachable Kit (ZQ) and Electrical Plate (EP) as per separate instructions. Fit Bolt Caps (BC).
4. Tighten all bolts. Re-mount exhaust.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

