| WITTER Fitting Instructions | TOWBAR For Jaguar X Type Saloon(2001 -) | For J13B |
|--|---|---------------------|
| MATERIALS | Estate(2004 -) | J13BQ |
| A 1 Cross Bar D 1 Side Arm (left hand) E 1 Side Arm (Right hand) F 4 Bushes (19mm O.D. 94mm long) | | |
| G2Forged Steel Spacer (ZSB1)H6M12 x 30 x 1.75mm Bolts, Nuts and Lock WashersJ4M12 x 120 x 1.75mm Bolts,Lock Washers and Large Flat Washers | s (40mm O D) | |
| L1M10 x 25 x 1.5 Bolt, Nut, Lock Washer and 2 Flat Washers (20mm)M1Electrical Mounting Plate (ZEP1)N1Electrical Mounting Plate Angle (ZEQ2) | n Ö.D) | |
| With later models, generally have reversing sensors; remove the lower bl. rearwards). With earlier models, having a gently curved profile to the low (2 Torx screws in the lower mud guard, 1 upper tip bolt and 1side bolt bel inside trim each side. 4 nuts along the rear panel inside and 3 plastic plug as shown. | rer black valence, remove the t hind the mud guard, 2 bolts be | oumper. hind the |
| Temporarily lower the rear exhaust silencers. Insert Bushes (F) and Bolts chassis. Loosely attach Side Arms (D and E) to Bolts (J). Loosely attach Cross Bar (A) to Side Arms (D and E) using Bolts (H). Tigl Attach Centre Part (ZF), Spacers (G) and Angle (N) using bolts (K), Elect using bolt (L) or attached to Neck (ZF) as shown. | hten all bolts and replace the b | umper. |
| J13BQ Detachable neck option – ZQ2031. Please refer to ZQ fitting instruction Please refer to the vehicle specification for the trailer weight and nose limits, wh Recommended torque settings: Grade 8.8M8 - 27Nm, M10 - 53 Nm, M12 - 9 Grade 10.9- M12 – 139Nm | ich must be observed . | 14 Nm |
| | E Juli | |
| INSIDE FACE | | |
| E 225 225 225 EXISTING HELES | H K L E | |
| H H H | | |

Ĥ

 $\overline{\mathbb{N}}$

M

G