



Fitting Instructions

TOWBAR KA14AU
For KIA RIO
HATCH
2006-
For use with
ZQ2030 and ZS2030 Necks only

MATERIALS

A	1	Cross Bar with European facing to 94/20/EC A50-1
D	4	M12 x 40 x 1.25 Bolts, Lock Washers and 30mm O.D. Flat Washers
Z	1	Electrical Plate (ZEP 2)
SC	1	Safety Chain Plate

FITTING

No need to remove bumper.

1. Release rearmost exhaust hanger to lower exhaust , remove clips along bottom edge of bumper.
2. Insert Crossbar (A) inside lower edge of bumper (fit over exhaust first) and loosely secure using (Bolts (D))
3. Fully Tighten Bolts and secure exhaust and bumper.
4. Please refer to ZQ/ZS fitting instruction for fitting of Detachable Kit, fit electrical plate (Z).

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

