WIT		Fitting		Towbar for: Kia Sorento MQ4 (MY2020-) KA53AU Hyundai Santa Fe P/E TM (2021-)		
	Instructions		ons			
IATERIA						
<u> </u>	Crossbar					
8 1	Sidearm Plate					
) 1	Sidearm Brac					
2		75 bolt & Nyloc Nut (N	B pitch)			
V 1		75 bolt (NB pitch)	- - - - - - - - - -			
V1 1		75 bolt & Nyloc Nut (N				
(3) (1) 1		25 bolt & 25 dia washe				
(1 1 (1		25				
′1 1		25 bolt (NB: no washe				
E 1		lectric Plate Kit	er required)			
	Neck Kit					
ITTING:						
	/ remove the sp	are wheel from under t	the vehicle, see	e vehicle owner ma	anual.	
					ank lowering and supportir	ng & HEV
		ers removing. Lowerin				0
. Locate	the mounting p	oints on the chassis ra	ils and ensure	that the holes and	I faces are clear of mastic	and debris.
					170 x 50mm wide). Use a	
					f (see image below as gui	
	and fully tighter	(to correct torque set)	tings) Sidearm	Bracket (C) to the	right-hand chassis rail us	ing fixings (X
& Y1).			<u></u>			
		dearm Plate (B) to the				aa ()()
		Retractable Electrical I			learm Plate (B) using fixin	gs (v).
					eir correct torque setting	16
					t the spare wheel, ensuring	
	t foul the towbal				t the spare wheel, ensuin	ig numerit
docon			Grade 8.8 bolt	s): M6 - 10Nm, M [·]	12 - 95Nm, M16 - 200Nm	
	1				Ψ	
					X1 (C	
4	1 09	•	\frown	v		9
4			(A)	^		<
			\searrow	V		\backslash
1		X III				\succ
	$\mathbb{N}^{\mathbb{H}}$				0	(C)
9					0	\smile
ĥ					0	
Ц				0		
	(ZE)	He Ho I Loo		~		O
Y	\sim			(B) T	
)			
	3	8) _ 	(z	J)	e W1 W	h i
				N /	V V	11

[] Y1