



# Fitting Instructions

TOWBAR FOR:  
Tribute F60/F62

MHA9U

## MATERIALS:

A	1	Crossbar
B	2	Sidearms
C	4	Chassis Bushes
D	4	M12 x 90 x 1.75 bolt, M12 x 1.75 Nyloc, M12 x 40 Washer
E	6	M12 x 35 x 1.75, M12 x 1.75 Nyloc
ZE	1	Electric Plate
ZN	1	Neck Option

## FITTING:

1. Remove 4 M12 through bolts connecting galvanised tabs to the chassis.
2. Place sidearm (B) on the inside of the chassis rail, over the top of the galvanised tab, secure with fixings (D), when inserting the most rear bolts, insert the chassis bushes (C) into the chassis rail making sure the bolt goes through them. Hand tighten.
3. Attach the main bar (A) to the sidearms via fixings (E).
4. Torque up fixings E then D to the recommended torque setting.
5. Fix neck option and electrical plate (ZN, ZE)

**Recommended torque settings:** Grade 8.8 bolts: M10 - 52 Nm, M12 - 95 Nm

