



Fitting Instructions

Detachable towbar fitting Autotrail Models:
COMANCHE
ARAPAHO
CHIEFTAIN

Towbar
MHK1U

MATERIALS

A	1	Crossbar
D	2	Sidearms
E	4	M12 x 35 x 1.75 bolts, Flat Washers (40mm) and Nyloc Nuts
F	4	M12 x 35 x 1.75 bolts and Nyloc Nuts
BC	2	Bolt caps
ZQ	1	Detachable unit
ZE	1	Electrical plate

Fitting Procedure:

1. Loosely attach Side plates (D) to existing holes in chassis using Bolts (E) with flat washers fitted to inside face of chassis.
2. Attach Crossbar (A) to Side plates (D) using Bolts (F)
3. Fit Detachable unit (ZQ) referring to separate fitting instruction
4. **Fully Tighten Bolts** ensuring crossbar is positioned square and approximately 10mm from bottom edge of valance.

Recommended torque settings: Grade 8.8 bolts: M8 - 24Nm, M10 - 52 Nm, M12 - 95 Nm, M14 - 130 Nm, M16 - 200 Nm

