



# Fitting Instructions

TOWBAR **MR39**  
For MERCEDES SPRINTER  
TWIN WHEEL (NOT WITH STEP)  
-MAY 2006 ON

## MATERIALS

A	1	Cross Bar with European facing to 94/20/EC A50-1
B	1	Coupling Packer
D	8	M12 x 100mm x 1.75mm Bolts, Nyloc Nuts and 30mm Flat Washers
EC	2	Plastic end caps
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers

**Note:** A fuel tank shield may be required – refer to vehicle handbook.

## FITTING

1. Remove towing eye from right hand chassis rail, loosely attach Cross bar (A) to existing bushed holes in vehicle chassis using Bolts (D) with Flat Washers fitted as shown below.
2. Fully tighten bolts and fit Plastic End Caps (EC) over open ends of Cross bar (A).

**Note:** This towbar must be used with a Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

