



Fitting Instructions

TOWBAR R38AU
For LAND ROVER FREELANDER

MATERIALS

A	1	Cross Bar
B	1	Electrical Plate (ZEP2)
D	6	M10 x 30mm Bolts and Lock Washers
E	2	M12 x 75mm x 1.25 Pitch Bolts, Lock Washers and Flat Washers (30mm O.D.)
ZQ	1	Quantum Detachable (ZQ2034)

FITTING

1. Remove bolts securing towing eye to inboard face of vehicle chassis - discard bolts (3 off). Remove tape from rear cross member to reveal existing mountings for Bolts (E). Loosely secure Cross Bar (A) to vehicle chassis using Bolts (D) and to rear cross member using Bolts (E).
2. Assemble Electrical Plate (B) and detachable towball housing (ZQ) as per separate fitting instructions.
3. Finally, **Tighten all Bolts.**

Note: This towbar must be used with a detachable Witter Towball (part number ZQ2034)

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed.**

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

