



# Fitting Instructions

Towbar for -  
Volkswagen Touran (2003-2015) VW52CU-FIT

For use with 3022 Series Necks

## MATERIALS:

A	1	Crossbar
D	4	M10 x 35 x 1.5 Bolts, Lock Washers and Flat Washers (30mm O.D) <b>Grade 10.9</b>
ZE	1	Electric Plate Kit
ZN	1	Chosen Neck

## FITTING:

1. Remove the bumper, 6 Torq head screws in each wheel arch, 1 Torq head screw in each lower corner of bumper, 4 screws along lower edge of bumper and 2 screws under each light cluster. (**Note:** Light cluster is held on by 2 screws under plastic trim on side of lights, and slides off sideways)
2. Remove crash beam and hand to end user for re-fitting when bar is removed.
3. Insert the Crossbar (A) into the chassis rails and loosely attach using fixings (D).
4. Attach Chosen Neck (ZN) and Electrical Plate Kit (ZE) as per separate fitting instruction. (**Tighten all Bolts**)
5. Cut bumper as shown and refit. (**Note:** It is advisable to protect outer face of bumper whilst refitting). If a flip up electrical socket is required, the bumper may need to be trimmed to suit. If using a Fixed Neck option it may be necessary to cut a 50mm slit from the bumper cut out to the bumpers edge thus enabling the bumper to pass over the neck.

## Note:

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.  
**Recommended torque settings:** M12 - 95 Nm (**Grade 8.8**) / M10 - 75 Nm (**Grade 10.9**)

