



Fitting Instructions

TOWBAR
For Volkswagen T-Cross VW99U
12 / 2018-

MATERIALS:

A	1	Crossbar
B	2	M12 x 40mm x 1.75 Bolt, Washers (x2) & Nyloc Nut
C	2	M12 x 40mm x 1.75 Bolt & Washer
D	1	Electrics Bracket
ZE	1	Rotatable Electric Kit
ZN	1	Chosen Neck

FITTING:

1. At each side of the luggage compartment pull back the interior trim to allow access to a large plastic fixing. By hand, unscrew this to enable removal of the rear light clusters. Unclip the wiring and slide the lights out.
2. Remove fixings from within the wheel arches.
3. Remove fixings from along the edge of the bumper.
4. Ease away the wheel arch trim from the vehicle body enabling access to a fixing behind. Remove fixing from each side.
5. Starting at the bumper tips, ease the bumper away from its plastic fixings. Unplug connected wiring.
6. Remove the bumper beam and fixings. Return to the customer.
7. Locate the mounting points on the outer face of each chassis and ensure that they are free from mastic or debris.
8. Slide Crossbar (A) into the chassis openings and attach loosely using fixings (B) & (C).
9. **Align & fully tighten ALL fixings to their correct torque settings.**
10. Attach Chosen Neck option (ZN), Electrics Bracket (D) & Electric Kit (ZE).
11. Cut the bumper using the diagram below **as a guide** & re-fit. Larger cut out is only required when using rotating electric plate.

Recommended torque settings: Grade 8.8 bolts: M12 - 80 Nm, M16 – 200Nm

